

Battery testers: Paralell system

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Paralell system



The paralell system is a paralell connection of maximum 4 pcs of Forex battery testers

Rating: Not Rated Yet

[Ask a question about this product](#)

Description

The paralell system is a paralell connection of maximum 4 pcs of Forex battery tester. (maximum 4 pcs of 24V - 100 A or , ___48V 100A , or ___12V -420A)

Maximum charging current

12V system: 1-1680A

24-48V system: 1-400A

printer: yes (option)

PC connection

software+cable