

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Warning: file_put_contents(/260717.ini): failed to open stream: Permission denied in /home/forexkft/public_html/en.forex.hu/libraries/joomla/filesystem/file.php on line 440

Tester 12/25



Forex Battery Tester LCD display 12V 0.3-25A RS232 software+cable with charger connection

Rating: Not Rated Yet

[Ask a question about this product](#)

Description

Technical Data:

Measured Voltage Range: 6-18V

Max. Input Voltage : 16V

Min Input Voltage: 6V

Discharging current: 0.3-25 (0.1 A steps)

Current error: +2% + 0.05A

Cut off voltage 6-15 V

Charging time: 1h -99 h

Max Number of cycles: 8

Dimensions 200*140*190 [mm]

Weight. 2 Kg

[Data sheet \(pdf\)](#)